

User Programmable Scan

Depending on how your T2020II is programmed, you may be able to change the channels that are included in your scan group. Existing channels can be removed and new channels can be added, as required.

Edit the user programmable scan group, as follows:

1. Press the **Function** (Fn) key.
 2. Scroll through the items in the display window using the **Up** and **Down** (▲/▼) keys, until “PROG GRP” is displayed.
 3. Press the **Enter** (↔) key. The name of the group is displayed, and the top row of indicators is illuminated.
 4. Press the **Enter** key a second time to start the editing the group.
 5. Press the **Up** and **Down** keys to scroll through all the available channels. The **SCAN** indicator indicates those channels that are included in the user programmable scan group, and a flashing **SCAN** indicator indicates the home channel.
 6. To add or delete a channel from the scan group, select the required channel and then press the **Enter** key.
- Note:** A scan group must contain 2 to 16 channels.
- The home channel is defined by selecting a channel and then holding the **Enter** key for longer than 1 second. The **SCAN** indicator then flashes.
- Note:** You can only delete a normal channel from the scan group. If the home channel is to be deleted from the scan group, you first have to define another channel as home channel and then delete the original home channel.
7. Once the group editing is complete, press the **Function** key to return to the Function menu.
 8. Press a mode key to switch to another mode, if desired. Alternatively, the inactivity timer returns the radio to the normal operating mode if no operator activity has been detected for 10 seconds.

